



# VISTA LIFEGUARD CHAIR

## ASSEMBLY INSTRUCTIONS



**SRS AUSTRALIA, PTY LTD**  
12 Enterprise St  
Richlands QLD 4077  
Australia  
Phone 07 3812 2283 • Fax 07 3812 1187  
[www.srsmith.com/au](http://www.srsmith.com/au)

**S.R. SMITH, LLC**  
CORPORATE HEADQUARTERS  
P.O. Box 400 • 1017 S.W. Berg Parkway  
Canby, Oregon 97013  
USA  
Phone (503) 266 2231 • Fax (503) 266 4334  
[www.srsmith.com](http://www.srsmith.com)

# INTRODUCTION



The Vista Lifeguard Chairs are designed for use on commercial pools. Proper and complete assembly, use, and maintenance are essential for proper operation and to reduce the risk of accident or injury.

## **\*\*IMPORTANT\*\***

Check entire box and inside all packing materials for parts. Before beginning assembly, read the instructions and identify parts using the figures and parts listed in this document. It is critical that all parts be carefully inspected by the installer prior to installation to ensure that no damage occurred in transit and that a damaged part is not used. Proper installation cannot be overstressed, as an improper installation voids S.R. Smith's warranty and may affect the safety of the user.

### **VISTA 6' (1.8m) to seat US48500-MG**

Dimensions are in feet/inches and (millimeters)



**FIGURE 1**


## VISTA PARTS LIST

ITEM NO.	QTY.	PART NO.	DESCRIPTION
1	1	8-609	LIFEGUARD SEAT
2	1	2407030	SWIVEL, LIFEGUARD CHAIR
3	1	8-612	FOOTBOARD, 30" X 42"
4	2	8-510	GASKET, 7-1/2" X 7-1/2"
5	1	13-117-MG	SWIVEL STAND, W/O UMBRELLA HOLDER, 316 S/S
6	1	20-202-MG	SWIVEL STAND MOUNTING PLATE, 316 S/S
7	2	FC-100A	20" FULCRUM COVER W/ SLOT
8	1	20-118-MG	UMBRELLA HOLDER ASSEMBLY, 316 S/S
9	18	800-1199	FLAT WASHER, 1/2", 316 SS
10	2	5-526	1/2" X 5-1/2" BOLT, 316 S/S
11	4	5-124	BOLT, 1/2" UNC X 3.0 LG
12	6	05-14-115-MG	LOCK WASHER, 1/2", SS
13	6	05-14-116-MG	1/2" HEX NUT S/S
14	4	05-618	NUT CAP, 1/2", WHITE PLASTIC
15	4	2300300-MG	CARRIAGE BOLT, 3/8" UNC X 4" LONG, 316 S/S
16	14	2020049-MG	CARRIAGE BOLT, 3/8" UNC X 2-1/2" LONG, 316 S/S
17	6	5-151-MG	LOCK WASHER, 3/8", SPLIT, 316 S/S
18	26	5-139-MG	3/8" UNC, HEX NUT, 316 S/S, 6FT VISTA
19	2	5-149	LOCK WASHER, 1/4", SPLIT, SS
20	2	5-137	HEX NUT, 1/4" UNC, SS
21	1	2024189	SCREW, 1/4" X 3/4" LG, PAN HD, SLOTTED, SS
22	1	20-121-MG	REAR FRAME ASSEMBLY, 6FT VISTA
23	2	20-124	FRONT CROSS TUBE, VISTA
24	2	20-125-MG	BOTTOM RAIL, 6FT VISTA
25	1	20-122-MG	LEFT FRONT RAIL ASSEMBLY, 6FT VISTA
26	1	20-123-MG	RIGHT FRONT RAIL ASSEMBLY, 6FT VISTA
27	4	2350105	TREAD, WHITE, 15 DEGREE, 6FT VISTA
28	8	5-145	FLAT WASHER, 3/8", SS, 6FT VISTA
29	8	5-167	CRADLE HEAD BOLT, 3/8" X 3-1/4" LG, SS, 6FT VISTA
30	2	8-862	PLS 6" WHEEL
31	2	8-104	PLASTIC RAIL END PLUG
32	12	2019061-MG	SPLIT TEE HALF, 316 S/S


## ASSEMBLY INSTRUCTIONS

1. Begin by locating the rear frame, front cross tubes (2), and the split tees as shown in **FIGURE 3**. Attach front cross tubes to the rear frame by sliding over the inserts as shown in **FIGURE 3**. (Do not bolt cross tubes in at this time) Attach (4) split tee halves at the top of the rear frame using (4) 3/8"x2-1/2" carriage bolts and (4) 3/8" hex nuts. NOTE: Do not tighten any hardware until final step.

Stand rear frame up and attach both front rails by inserting the top into the split tees already on the rear frame and the stainless inserts into the front cross tubes. See **FIGURE 4**




**FIGURE 3**



**FIGURE 4**


2. Attach the four 15° white steps using the supplied pre-packaged hardware. Each step is fastened using (2) 3/8" Cradle head bolts, 3/8" flat washers, and 3/8" hex nuts. See **FIGURE 4**.



**FIGURE 5**


3. Attach footboard to both cross tubes using (4) 3/8"x4" carriage bolts, 1/2" flat washers, 3/8" lock washers, and 3/8" hex nuts. Attach the two bottom rails with (8) split tee halves, 3/8" x 2-1/2" carriage bolts and 3/8" hex nuts. See **FIGURE 5**.

- Place Swivel onto Swivel Stand W/O Umbrella Holder orienting as shown in **FIGURE 6**. Place Screw through Swivel and Swivel Stand (4 places) as shown in **FIGURE 6**. Place 1/4" Lock Washer and 1/4" Hex Nut onto Screw and tighten (4 places).




**FIGURE 6**

- Attach the seat assembly to the footboard using (4) 1/2"x3" hex head bolts, (8) 1/2" flat washers, (4) 1/2" hex nuts, (4) 1/2" lock washers, (4) 1/2" plastic nut caps and (1) mounting plate as shown in **FIGURE 7**. A rubber gasket is placed both above and below the footboard, in-between the stainless steel plates.



Handrail Removed For Clarity


**FIGURE 7**



**FIGURE 8**

- Attach the umbrella holder using (2) 3/8"x2-1/2" carriage bolts, 1/2" flat washers, 3/8" lock washers and 3/8" hex nuts. See **FIGURE 8**.

7. Install the 6" (15.2cm) wheels using (1) 1/2"x5-1/2" hex head bolt, (2) 1/2" flat washers, and (1) 1/2" lock washer and (1) 1/2" hex nut as shown in **FIGURE 9**.
8. Attach the front rubber protective pads and fully tighten all hardware. See **FIGURE 9**.



**FIGURE 9**

### **SAFETY & MAINTENANCE INSTRUCTIONS**

- Do not dive or jump from any part of this guard chair.
- Periodically inspect the VISTA to assure there are no worn parts and that all hardware is properly tightened.
- All stainless steel parts require periodic maintenance. Polishing with a cotton cloth and a mild cleaning product maintains the finish and restores luster.
- Use non-abrasive soap and water. Avoid harsh chemicals and disinfectants. Always read the label instructions on any cleaner carefully before applying it to a surface.