



SPLASH BASE REPLACEMENT INSTRUCTIONS

For more information about the Splash!™ base replacement process and to see video demonstrating the replacement process, please visit www.splashpalliftinfo.com or scan the QR code.

REQUIRED TOOLS	CONTENTS OF SPLASH BASE REPLACMENT PACKAGE	
3/4" deep socket wrench 9/16" wrench Box cutter	Contact S.R.Smith if you are missing items. Hardware Packet Two—1/2" Nylock Nuts SS Two—1/2" 316 SS Washer One—3/8" 1.25 Hexhead One—3/8" x 7/8" Flat Washer SS One—3/8" Nylon Protective Washer	Base Assembly Packing Tape Return Shipping Label Product Registration Form
	One—3/8" Lock Washer, Split S/S	

BE SURE TO SAVE ALL PACKAGING MATERIALS; YOU WILL RE-USE THEM TO PACKAGE UP THE EXISTING BASE AND SEND BACK TO S.R.SMITH FREE OF CHARGE.

Carefully open package.

Set aside the shipping label you will need for sending the base back to S.R.Smith.

Tilt box on its side and carefully slide the replacement base out onto a nonscratch surface.



Using a 3/4" socket wrench, remove the nuts holding the handle in place, remove the handle, wood spacer and foam.

Set aside.



Remove the battery from the LiftOperator.

Disconnect the motor cord, actuator cord and hand control from the LiftOperator.



Remove the thumb nut and bolt on the back of the lift seat to remove the seat assembly.





(888) 497-9290 www.splashpalliftinfo.com 5

This step may require two people.

Remove round cap to expose the base.



6

This step may require two people.

Have one person hold the mast steady. Using a ¾" deep well socket wrench, remove the two nuts which connect the mast to the base.



7

This step may require two people.

Separate the mast from the base. Carefully place the mast on a nonscratch surface.



8

Attach the foam sheet and wood packaging spacer onto the base and tighten the bolt.



9

If the lift features a lift lock tab, remove the nut with a 9/16" wrench.



10

Use the handles to carefully pull the base out of the anchor.



П

Place the foam block onto the base stem and slide the assembly into the shipping carton.



12

Install the new base into the anchor. If a bolt was removed in step #9, re-attach lift lock anchor bolt.



13

This step may require two people.

Re-attach the mast assembly with the new hardware provided.

Using a ¾" wrench, fully tighten the nuts.



Re-attach the battery and connect the motor cord, actuator cord and hand control.

Conduct a complete function test of the lift (refer to your pool lift owner's manual for complete details.)



15

Complete the product registration form, insert into the box with the old base.

Reseal the box with the packing tape provided.

Please co S.R. Smith	onglete the form below and insert it in the box with the Splash base you are λ	neturning to
SPLASH	POOL LIFT REGISTRATION	
Contact	inal:	
Contact	Name	
TEK_		
Facility N	lane:	
Spreet Au	ldresc	
city		
Lift Seria	Number	
$\overline{}$	Check box to confirm the new Splack I base has been installed. Date installed:	
FAQ		Than.
Where is	the product serial number located?	-
The mod the mast	el number and serial number of the lift is located on the lower portion of :	_G <u>≅</u>
Where c	an I get more information?	Product Label
and view	of www.quadqualithinfo.com to find information about the assembly repla video demonstrating how the replacement is done or contact our custome 14390, email <u>paties to the transition on the com-</u>	

16

For detailed shipping information, please refer the enclosed orange paper marked 'RETURN SHIPPING INSTRUCTIONS.'



RESOURCES

Website: www.splashpalliftinfo.com

Customer Service: (888) 497-9290

FedEx Website: www.fedex.com

FedEx Pick Up: (800) 463-3339

WARRANTY INFORMATION

The Splash! base replacement assembly is covered by a two year warranty upon receipt.

We are also extending the original warranty for structural components of your lift from three years to five years from date of manufacture.

For more information, visit:

http://srsmith.com/en-us/customer-service/warranty-information/

(888) 497-9290 www.splashpalliftinfo.com